



Rif.	Codice	Descrizione
1	HCSF05ATU.01	Cavo - Cable
2	HCSF05AUF.02	Passacavo - Cable base
3	HCSF05ATU.03	Supporto superiore - Upper cover
4	HCSF05AUF.04	Piastrina passacavo - Cable base cover
6	HCSF05AUF.06	Coperchio - bracket
9	HCF21U.09	Rotore - Shaft with rotor
10	HCSF21ATU.10	Motoprotettore - Auto-Cut
13	HCSF21ATU.13	Motore completo - Complete motor
17	HCF05UF.17	Olio dielettrico - Lubricant
19	HCSF05AUF.19	Supporto porta cuscinetti - Bearing bracket
20A	HCF05UF.20A	Cuscinetto superiore - Upper bearing
20B	HCF05UF.20B	Cuscinetto inferiore - Lower bearing
21	HCSF05AUF.21	Tenuta meccanica - Mechanical seal
23	HCSF05AUF.23	Portatenuta - Mechanical seal bracket
25	HCSF05AUF.25	Anello corteco - Oil seal
26	HCSF05AUF.26	Corpo pompa - Casing
27	HCSF21AUF.27	Girante - Impeller
36	HCSF05AUF.36	Flangia - Flange
41	HCF05UF.41	Maniglia - Handle
46	HCSF21AUF.46	Chiavetta - Impeller key
47	HCSF05AUF.47	Set guarnizioni - Packing (1 set)
55	HCF05UF.55	Tappo - Oil Plug